OPERATING INSTRUCTIONS:
Dryer

- Clean lint screen before each use
- Sort and load clothes
- Close door
- Select DRYING Cycle
- Press "START" button